



# User Guide

LTE-Advanced Mobile Wi-Fi  
M7450 / M7650

# Contents

About This Guide .....	1
<b>Chapter 1. Get to Know About Your Mobile Wi-Fi.....</b>	<b>2</b>
1. 1. Product Overview.....	3
1. 2. Physical Description.....	4
1. 2. 1.The Exterior.....	4
1. 2. 2.The Interior .....	6
<b>Chapter 2. Set Up Internet Connection .....</b>	<b>7</b>
2. 1. Install the Hardware.....	8
2. 1. 1.Installation .....	8
2. 1. 2.Power On .....	9
2. 2. Connect to the Mobile Wi-Fi .....	10
<b>Chapter 3. Login .....</b>	<b>16</b>
3. 1. Via Phone Login Entry .....	17
3. 2. Via PC Login Entry .....	17
3. 3. Via tpMiFi App .....	18
<b>Chapter 4. Manage Your Data Usage .....</b>	<b>20</b>
4. 1. Track Data Usage.....	21
4. 1. 1.Check Data Usage on Screen.....	21
4. 1. 2.Check Data Usage on the Web Management Page.....	21
4. 1. 3.Check Data Usage via SMS.....	22
4. 1. 4.Revise Data Usage .....	23
4. 2. Limit Data Usage .....	24
4. 2. 1.Limit Data Package.....	24
4. 2. 2.Limit Monthly Data Usage .....	25
4. 3. Set up Free Data Period.....	26
4. 4. Enable Mobile Data .....	27
4. 5. Enable Data Roaming .....	28
<b>Chapter 5. Secure Your Network .....</b>	<b>30</b>
5. 1. Secure Wireless Network .....	31
5. 2. Block Unwelcome Devices.....	32

5.3.	Lock SIM Card .....	33
<b>Chapter 6. Share Files on SD Card.....</b>		<b>36</b>
6.1.	Access via Wi-Fi Mode.....	37
6.2.	Access via USB Mode.....	40
<b>Chapter 7. Customize Your Network.....</b>		<b>42</b>
7.1.	Specify Network Mode .....	43
7.2.	Specify Network Band .....	44
7.3.	Configure Dial-up.....	46
	7.3.1.Configure Dial-up Settings .....	46
	7.3.2.Configure Network Search .....	47
7.4.	Configure DHCP Server.....	48
<b>Chapter 8. NAT Forwarding.....</b>		<b>50</b>
8.1.	Translate Address and Port by ALG.....	51
8.2.	Share Local Resources on the Internet by Virtual Servers.....	52
8.3.	Open Ports Dynamically by Port Triggering.....	53
8.4.	Make Applications Free from Port Restriction by DMZ .....	54
8.5.	Make Xbox Online Games Run Smoothly by UPnP .....	55
<b>Chapter 9. Manage Your Mobile Wi-Fi .....</b>		<b>57</b>
9.1.	Save the Mobile Wi-Fi's Power .....	58
9.2.	Change Login Password .....	60
9.3.	Set Up System Time .....	60
9.4.	Restore Configuration Settings .....	61
9.5.	Update the Firmware .....	62
9.6.	Update ISP Parameters .....	63
9.7.	USSD.....	64
9.8.	System Log.....	65
<b>FAQ .....</b>		<b>67</b>



# About This Guide

This guide is a complement of Quick Installation Guide. The Quick Installation Guide provides instructions for quick internet setup, while this guide contains details of each function and demonstrates how to configure them.

When using this guide, please notice that features of the Mobile Wi-Fi may vary slightly depending on the model, the software version you have, your location, system language, and internet service provider. All screenshots, images, parameters and descriptions documented in this guide are used for demonstration only.

## Conventions

In this guide the following conventions are used:

Convention	Description
<u>Underlined</u>	Underlined words or phrases are hyperlinks. You can click to redirect to a website or a specific section.
Teal	Contents to be emphasized and texts on the web page are in teal, including the menus, items, buttons and so on.
>	The menu structures to show the path to load the corresponding page. For example, <a href="#">Advanced</a> > <a href="#">Wireless</a> > <a href="#">Black List</a> means the Black List page is under the Wireless menu that is located in the Advanced tab.
 <b>Note:</b>	Ignoring this type of note might result in a malfunction or damage to the device.
 <b>Tips:</b>	Indicates important information that helps you make better use of your device.

## More Info

The latest software, management app and utility are available at [Download Center](#) at [www.tp-link.com/support](http://www.tp-link.com/support).

The Quick Installation Guide can be found in the same place you found this guide or inside the package of the Mobile Wi-Fi.

Specifications can be found on the product page at <http://www.tp-link.com>.

A Technical Support Forum is provided for you to discuss our products at <http://forum.tp-link.com>.

Our Technical Support contact information can be found at Contact Technical Support page at [www.tp-link.com/support](http://www.tp-link.com/support).

## Chapter 1

---

# Get to Know About Your Mobile Wi-Fi

---

This chapter introduces what the Mobile Wi-Fi can do and its appearance. It includes the following sections:

- [Product Overview](#)
- [Physical Description](#)

## 1.1. Product Overview

### **The Faster Connections, The More You Can Do**

Just insert a 4G SIM card to create your reliable personal Wi-Fi hotspot and share instant 4G/3G connectivity with friends. The Mobile Wi-Fi, supporting the latest generation 4G LTE network, can reach a faster download speed so that users can enjoy HD movies without interruption, download files in seconds, and hold a video chat without dropouts.

### **Artful Little Gadget and Built-in Battery for Life on the Go**


The TP-Link Mobile Wi-Fi features a compact, elegant design and rechargeable powerful battery very suitable for travel, business trips and outdoor activities. With added flexibility, the device can be charged via a micro USB cable connected to an adapter, laptop or portable charger for endless hours of 4G sharing.

### **Easy Management with the tpMiFi App**

With the tpMiFi App, you can conveniently access and manage the Mobile Wi-Fi right on your iOS/Android devices. The tpMiFi app allows you to set data limits, control Wi-Fi access, send messages, and share media files to/from a removable micro SD card.

## 1.2. Physical Description







### 1.2.1. The Exterior












### Button Explanation

Button	Description
Menu Button	<ul style="list-style-type: none"> <li>• Press to enter the Menu Screen from the Home Screen.</li> <li>• Press to switch between icons or options.</li> <li>• Press to light on the screen.</li> </ul>
Power Button	<ul style="list-style-type: none"> <li>• Press and hold to power on/off the Mobile Wi-Fi.</li> <li>• Press to turn on/off the screen display.</li> <li>• Press to select an icon.</li> </ul>


## Screen Display

Home Screen	Displayed Item	Indication
		Indicates the signal strength of the current network.
	4G/3G/2G	Indicates successful network connection and the current network type: 4G, 3G or 2G.
		Indicates you are in roaming service.
		Indicates that there is un-read message(s) and the number of them.
		Displays the Wi-Fi status and the number of connected wireless devices.
	100% 	Displays the remaining battery power.
	560MB	Indicates the total data used. It will be cleared after the Mobile Wi-Fi is reset.
	5.0 M/S ↓	Indicates the current download speed of the data transmission.

Menu Screen	Menu	Description
	 Home	Displays the information of data, signal strength, battery life and so on.
	 Device Info	Displays the SSID (network name), password and login address of the Mobile Wi-Fi.
	 Power Saving	If enabled, the Wi-Fi will be shut down if no wireless devices are connected to the Mobile Wi-Fi for 10 minutes; and the Wi-Fi range will be medium. For more information, please refer to <a href="#">Save the Mobile Wi-Fi's Power</a> .
	 WPS	To enable the WPS function. Enable this function and immediately press the WPS button on your wireless device. A success message will appear on the screen, indicating successful WPS connection.
	 Wi-Fi Band	To change the Wi-Fi band to 2.4GHz or 5GHz as needed.
	 Network Mode	To change the network mode: 4G preferred, 4G only or 3G only as needed.
	 Data Roaming	To enable or disable the Data Roaming function as needed. We recommend you to enable it when you are out of the mobile carrier service area.
	 App Download	Scan the QR code to download the tpMiFi app to manage your Mobile Wi-Fi.



## 1.2.2. The Interior



Item	Description
Micro SIM Card Slot	Insert a SIM card into the slot. A nano SIM card must be converted using the provided SIM card tray.
Micro SD Card Slot	Slide and lift up the slot cover, insert a SD card and slide the cover back to lock. The inserted SD card can be used for storage and media sharing.
Micro USB Input Port	Plug in the USB cable to this port to charge your Mobile Wi-Fi or share contents in the SD card.
Reset Button	With the Mobile Wi-Fi powered on, use a pin to press and hold this button until "Power Off" appears on the screen to reset the Mobile Wi-Fi.

## Chapter 2

---

# Set Up Internet Connection

---

This chapter introduces how to install the hardware and set up the internet connection of your Mobile Wi-Fi.


It includes the following sections:

- [Install the Hardware](#)
- [Connect to the Mobile Wi-Fi](#)


## 2. 1. Install the Hardware

### 2. 1. 1. Installation

1. Remove the cover and the battery.



2. Slide and lift up the SIM card slot cover and insert the SIM card. And then slide to lock the SIM card slot.



**Note:**


- A nano SIM card must be converted using the provided SIM card tray.
- The SIM card is not provided by TP-Link.

3. (Optional) Slide and lift up the SD card slot cover and insert a micro SD card. The inserted SD card can be used for storage and media sharing.

**Note:**

- To learn how to store and share files via the SD card, please refer to [Share Files on SD Card](#).
- The SD card is not provided by TP-Link.


4. Fit the battery into the slot.



5. Replace the cover.



### 2.1.2. Power On

Press and hold  (power button) until the welcome screen appears.




**Note:**

To power off, press and hold  (power button) until **Power Off** appears on the screen.

## 2.2. Connect to the Mobile Wi-Fi

1. After the Mobile Wi-Fi is powered on, you will see the following screen.



▮ Note: If other messages appear on the screen, please refer to [Q2](#) of [FAQ](#).


2. Follow the instructions to connect to the Mobile Wi-Fi. Here are two methods.

▮ Note: If you use a computer to connect to the Mobile Wi-Fi, please set your computer's setting to obtain an IP address automatically.


### Method One: Using SSID and Wireless Password

a. Find the SSID (network name) and wireless password from the screen or on the product label.

- On the screen:


- 1) Press  (menu button) to enter the Menu page and switch to the [Device Info](#) page.




- 2) Press  (power button) to enter the [Device Info](#) page.



- On the product label:
  - 1) Remove the cover and the battery of the Mobile Wi-Fi.
  - 2) Take down the SSID and Wireless Password printed on the product label.



- b. Go to Wi-Fi settings of your smart device or click the network icon of your computer, then select the **SSID** and enter the **Wireless Password** that you found to join the Wi-Fi.




## Method Two: Via WPS (Wi-Fi Protected Setup)

If you have a WPS-supported device (such as Android phones or tablets), you can connect to the Mobile Wi-Fi more easily using WPS button or PIN.


▀ Note:

To use the WPS function, please make sure the SSID Broadcast function and wireless function are enabled.



- Via the WPS button

1) Press  (menu button) to enter the menu page and switch to the **WPS** menu.



2) Press  (power button) to enter the **WPS** page.




3) Press  (menu button) and  (power button) together to enable the WPS function, and then the Mobile Wi-Fi starts to scan WPS-supported devices.



- 4) On your WPS-supported device, go to **Settings**, turn on **Wi-Fi**, and click **Connect via WPS** within 2 minutes.

**Note:**

The interfaces of the WPS function may vary in different wireless devices.



- 5) The status of WPS will change from **Connecting** to **Succeeded** indicating your WPS-supported device is connected to the Mobile Wi-Fi.








- Via the PIN
  - 1) On your WPS-supported device, go to [Settings](#), turn on [Wi-Fi](#), and go to the WPS page to get the PIN.

▮ Note:


The interfaces of the PIN verification may vary in different wireless devices.



- 2) Connect the Mobile Wi-Fi to your computer with a USB cable, visit <http://tplinkmifi.net>, and log in with the default password: [admin](#).



- 3) Go to [Device](#) > [Advanced](#) > [WPS](#), check the [PIN](#) box and enter the PIN of your WPS-supported device in the field.



- 4) Click [Start](#) to start the WPS process, and the Current Status will change from [Idle](#) to [Succeed](#) indicating your WPS-supported device is connected to the Mobile Wi-Fi.

## Chapter 3

---

# Login

---

This chapter introduces 3 methods to log in to the web management page. Demonstrations in this guide use the phone web management interfaces, while some use the computer as those functions are only available on the computer's web management page.


Before login, make sure your device is connected to the Mobile Wi-Fi's SSID. If not, refer to Chapter 2 for detailed instructions.

This chapter includes the following sections:


- [Via Phone Login Entry](#)
- [Via PC Login Entry](#)
- [Via tpMiFi App](#)

### 3. 1. Via Phone Login Entry

1. On your smart phone, visit <http://tplinkmifi.net>, and log in with the default password: `admin`.



2. Create a new login password for security purposes and click **Done**.




3. Use the password you just created for future logins.


### 3. 2. Via PC Login Entry

On the PC web management interfaces, you can enjoy more features, such as DHCP settings.

1. Visit <http://tplinkmifi.net> from the PC entry, and log in with the password: admin.



2. Go to **Wizard**, create a new login password for security purposes and click **Confirm**.




3. Use the password you just created for future logins.

### 3.3. Via tpMiFi App

1. Search "tpMiFi" at the App Store or Google Play Store or simply scan the QR code to download the tpMifi app.



2. Connect your device to the Mobile Wi-Fi.
3. Launch the [tpMiFi](#) app, create a new password for security purposes and click [Log In](#).



4. Use the password you just created for future logins.

## Chapter 4

---

# Manage Your Data Usage

---

This chapter explains how to manage the data usage of your Mobile Wi-Fi.

It includes the following sections:


- [Track Data Usage](#)
- [Limit Data Usage](#)
- [Setup Free Data Period](#)
- [Enable Mobile Data](#)
- [Enable Data Roaming](#)

## 4. 1. Track Data Usage

This feature allows you to monitor the amount of data you have used on your Mobile Wi-Fi and revise the displayed data usage as needed.

### 4. 1. 1. Check Data Usage on Screen

You can view data usage on the screen of your Mobile Wi-Fi.




### 4. 1. 2. Check Data Usage on the Web Management Page

1. Visit <http://tplinkmifi.net>, and log in with the password you set for the Mobile Wi-Fi.

■ Note: Before login, make sure your device is connected to the Mobile Wi-Fi's SSID.

2. You can view the data usage on the [Status](#) page as shown below.







■ Note:

1. Actual data usage may vary from the estimated data usage displayed on the usage meter.
2. The page above displays the monthly data usage if you have enabled Monthly Data Statistics.

#### 4. 1. 3. Check Data Usage via SMS

Your mobile carrier can provide more accurate data usage information. To obtain it, you can send messages to your mobile carrier.


1. Visit <http://tplinkmifi.net>, and log in with the password you set for the Mobile Wi-Fi.
2. Go to **SMS**.
3. Tap **New Message**.
4. Create a message to your carrier and then tap  to send it. And a few minutes later, you will receive a message of data usage information. For the phone number and message content, check from your carrier. Example below is from the mobile carrier China Unicom.



#### 4. 1. 4. Revise Data Usage

If the data usage displayed is not accurate, you can modify it as needed.

1. Visit <http://tplinkmifi.net>, and log in with the password you set for the Mobile Wi-Fi.
2. Go to **Device** > **Data Usage Settings**.
3. The figure below displays the current data usage. Tap **Correct**, enter a more accurate value for the data usage.



#### 4. Tap **Done**.

■ **Note:**

1. You can obtain the exact data usage from your carrier. Please refer to [Check Data Usage via SMS](#).
2. The page above displays the monthly data usage if you have enabled Monthly Data Statistics.

## 4.2. Limit Data Usage



This feature allows you to establish data limits for different data packages so that you can better control your data usage.


### 4.2.1. Limit Data Package

**I want to:** Limit my data usage so that I will not exceed my data package (2GB). I wish to:

1. Receive an alert when the data usage reaches 1.8GB (90% of the allowance).
2. Disable the internet access automatically when it reaches the allowance (2GB).

**How can I do that ?**

1. Visit <http://tplinkmifi.net>, and log in with the password you set for the Mobile Wi-Fi.
2. Go to [Device](#) > [Data Usage Settings](#).
3. Enable [Data Usage Limit](#).
4. Enter [2](#) in [Total Allowance](#) field and specify [GB](#) as the unit of measure. To inform you that your data usage has reached the allowance, the internet access will be disabled automatically and the data usage circle on the Home Screen will turn to red: .
5. Set [90](#) as the [Usage Alert](#) percentage. To inform you that your data usage has reached the alert value, the data usage circle on the Home Screen will turn to orange: .



6. Tap **Done**.

**Done!**

Now your data usage is limited according to your settings.

#### 4.2.2. Limit Monthly Data Usage


**I want to:**


Limit my data usage so that I will not exceed my monthly data package (800MB). I wish to:

1. Receive an alert when the data usage reaches 720MB (90% of the allowance);
2. Disable the internet access automatically when it reaches the allowance (800MB).

**How can I do that?**

1. Visit <http://tplinkmifi.net>, and log in with the password you set for the Mobile Wi-Fi.
2. Go to **Device > Data Usage Settings**.
3. Enable **Data Usage Limit** and **Monthly Data Statistics**.
4. Enter **800** in **Monthly Allowance** field and specify **MB** as the unit of measure. To inform you that your data usage has reached the allowance, the Internet access will be


disabled automatically and the data usage circle  on the Home Screen will turn to red.

5. Set **90** as the **Usage Alert** percentage. To inform you that your data usage has reached the alert value, the data usage circle  on the Home Screen will turn to orange.

6. Enter the **Start Date**.

**Note:**

The monthly data usage statistics will be cleared and recounted from the day you have set every month.



7. Tap **Done**.


**Done!**

Now your data usage is limited according to your settings.

### 4.3. Set up Free Data Period

In the free data period, you will not be charged for the data by the mobile carrier. If your carrier has provided this data service to you, you can specify the free data period during which the data usage will not be counted for data alert and limitation.

1. Visit <http://tplinkmifi.net>, and log in with the password you set for the Mobile Wi-Fi.
2. Go to **Device** > **Data Usage Settings**.
3. Enable **Free Data Period**.
4. Enter the **Start Time** and **End Time** of Free Data Period.




5. Tap **Done**.

## 4.4. Enable Mobile Data

With Mobile Data (also known as cellular data) enabled, devices connected to the Mobile Wi-Fi can access the internet. This feature is enabled by default.

1. Visit <http://tplinkmifi.net>, and log in with the password you set for the Mobile Wi-Fi.
2. Go to **Dial-up**.
3. Enable **Mobile Data**.



4. Tap **Done**.

## 4.5. Enable Data Roaming

If you are out of the network service area, you can use this feature as needed.


### Method One: Via the screen

1. Press **≡** (menu button) and switch to the **Data Roaming** menu.



2. Press **⏻** (power button) to enter the **Data Roaming** page.

3. Press **≡** and **⏻** to select **ON**.




### Method Two: Via the web management page

1. Visit <http://tplinkmifi.net>, and log in with the password you set for the mobile Wi-Fi.

2. Go to **Dial-up**.

3. Enable **Data Roaming**.



4. Tap **Done**.



## Chapter 5

---

# Secure Your Network

---

This chapter explains how to secure your network in various ways. You can change the SSID and wireless password, manage the blacklist and lock your SIM card to safeguard your network.

It includes the following sections:

- [Secure Wireless Network](#)
- [Block Unwelcome Devices](#)
- [Lock SIM Card](#)

## 5.1. Secure Wireless Network


The SSID (network name), wireless password of the Mobile Wi-Fi and security options are preset as default. The default SSID and password can be found on the screen of your Mobile Wi-Fi. You can customize the wireless settings as needed.

1. Visit <http://tplinkmifi.net>, and log in with the password you set for the Mobile Wi-Fi.

2. Go to [Wireless](#).

➤ **To change the SSID and wireless password**

1. Enter a new SSID and wireless password in the [Wireless Network Name](#) and [Wireless Password](#) fields respectively.




The screenshot shows the 'Wireless' settings screen. At the top, there is a teal header with the word 'Wireless' on the left and 'Done' on the right. Below the header, there are three main sections: 1. 'Wireless Network Name(SSID):' with a text input field containing 'TP-LINK\_2016'. 2. 'SSID Broadcast:' with a teal toggle switch that is currently turned on. Below this toggle is a teal note: 'Once SSID Broadcast is disabled, you need to manually type in the SSID to join the wireless network.' 3. 'Wireless Password:' with a text input field containing a masked password.

2. Tap [Done](#).

➤ **To hide the SSID**

1. Toggle off [SSID Broadcast](#), so the SSID will not be displayed when you scan for wireless networks.



The screenshot shows a close-up of the 'SSID Broadcast' toggle switch. The toggle is currently turned on (teal). Below the toggle is a teal note: 'Once SSID Broadcast is disabled, you need to manually type in the SSID to join the wireless network.'


2. Tap [Done](#).

■ **Note:**

If the SSID is hidden, it will not be displayed on your wireless device when you scan for local wireless networks. And you need to manually enter the SSID to join the wireless network.

➤ **To hide the password on screen**


1. Toggle off **Display password on screen**, so the wireless password will not be displayed on the screen of your Mobile Wi-Fi.




2. Tap **Done**.


## 5. 2. Block Unwelcome Devices

This feature allows you to restrict unwelcome devices to accessing the wireless network of your Mobile Wi-Fi.

1. Visit <http://tplinkmifi.net>, and log in with the password you set for the mobile Wi-Fi.
2. Go to **Status > Current Clients**.
3. Tap .



4. Select the device(s) that you want to block from the **Online Clients** list.



5. Tap **Block**.

### 5.3. Lock SIM Card

This feature allows you to lock your SIM card with the **PIN** lock. Once the **PIN** lock is enabled, every time you start your Mobile Wi-Fi with your SIM card inserted, you need to enter the PIN code to access the internet.

If you don't wish to enter the PIN code on your Mobile Wi-Fi, you can enable the Auto-unlock PIN upon Power-on function. You will still have to enter the PIN code on other devices to unlock this SIM card, however.

1. Visit <http://tplinkmifi.net>, and log in with the password you set for the Mobile Wi-Fi.


2. Go to **Device** > **Advanced** > **PIN Management**.

➤ **To enable the PIN lock**

1. Visit <http://tplinkmifi.net>, and log in with the password you set for the Mobile Wi-Fi.

2. Go to **Device** > **Advanced** > **PIN Management**. Toggle on **Enable PIN**.

3. Enter the PIN code of your SIM card.



4. Tap **Done**.

5. Visit <http://tplinkmifi.net> and then enter the PIN code to access the internet every time you start your Mobile Wi-Fi.


■ **Note:**

1. The PIN code of your SIM card is preset by your carrier and usually can be found on the package of the SIM card.
2. After 3 failed verification attempts, the SIM card will be locked, and you will need to enter the PUK code to unlock it. The PUK code can usually be found on the package of the SIM card, too.

➤ **To reset PIN code**

1. Visit <http://tplinkmifi.net> from the PC entry, and log in with the password you set for the Mobile Wi-Fi.
2. Go to **Advanced > Dial-up > PIN Management**.
3. Select **Enable PIN** from the drop-down list if SIM Card Status is disabled. Enter the PIN code of your SIM card, and then click **Apply**.
4. Select **Modify** from the drop-down list.
5. Enter the current PIN code and a new PIN code twice to complete the resetting.

■ **Note:** The new PIN code must consist of 4-8 digits.



**PIN Management**

SIM Card Status: PIN verified

PIN Management: Modify

PIN: 1234 Remaining Attempts: 3

New PIN: 12345

Confirm PIN: 12345

Auto-unlock PIN upon Power-on:

Apply

6. Click [Apply](#).


7. Use the new PIN code for future PIN verifications.

➤ **To enable Auto-unlock PIN upon Power-on**

1. Visit <http://tplinkmifi.net>, and log in with the password you set for the Mobile Wi-Fi.

2. Go to [Device](#) > [Advanced](#) > [PIN Management](#). Toggle on [Enable PIN](#), enter the PIN code of your SIM card, and tap [Done](#).

3. Enable [Auto-unlock PIN upon Power-on](#).



**PIN Management** Done

SIM Card Status: PIN verified

Enable PIN:

PIN:

Remaining Attempts: 3

Auto-unlock PIN upon Power-on:

4. Once enabled, you can save the trouble of entering the PIN code on your Mobile Wi-Fi.

## Chapter 6

---

# Share Files on SD Card

---

This chapter describes how to share and access files on an SD card via Wi-Fi and via a USB cable.


It contains the following sections:

- [Access via Wi-Fi Mode](#)
- [Access via USB Mode](#)

## 6. 1. Access via Wi-Fi Mode

You can share files on an SD card via Wi-Fi mode so clients connected to the Mobile Wi-Fi can access the SD card.


1. Visit <http://tplinkmifi.net>, and log in with the password you set for the Mobile Wi-Fi.
2. Go to **Device** > **Advanced** > **Storage Sharing**.
3. Select **By Wi-Fi** for Access Mode.



The screenshot displays the 'Storage Sharing' configuration interface. At the top, there is a teal header with a back arrow, the title 'Storage Sharing', and a 'Done' button. Below the header, the 'Access Mode' is set to 'By Wi-Fi'. The 'Login Permission' is set to 'Signed'. The 'Username' field contains 'admin' and the 'Password' field also contains 'admin'. At the bottom of the screen, there is a menu with three options: 'By USB', 'By Wi-Fi', and an empty space. The 'By Wi-Fi' option is currently selected and highlighted.

4. Select **Signed** or **Anonymous** for Login Permission.



**Note:**

If you have selected **Signed**, please specify Username and Password for the access (admin by default).

5. Tap **Done**.

6. Access the storage sharing:

➤ **To access via an Android or iOS device**

1. Search **tpMiFi** at the App Store Store or Google Play Store or simply scan the QR code to download it.



2. Connect your mobile device to the Mobile Wi-Fi.


3. Launch **tpMiFi** and enter the password you set for the Mobile Wi-Fi.

4. Tap **SD Sharing** to access the SD card. You can then view, download and upload multimedia files as needed.



➤ **To access the SD card via a PC**

1. Connect your computer to the Mobile Wi-Fi.
2. Open **Run** and input "`\\192.168.0.1`" (by default) or `ftp://192.168.0.1`. Then click **OK** to continue.




3. For anonymous access, you can now access the SD card. For signed access, enter the login username and password in the authentication window and click **OK**. Then you can access the SD card.



## 6.2. Access via USB Mode


You can connect your computer to the Mobile Wi-Fi via a USB cable to access the SD card directly.

1. Visit <http://tplinkmifi.net>, and log in with the password you set for the Mobile Wi-Fi.
2. Go to **Device** > **Advanced** > **Storage Sharing**.
3. Select **By USB** for Access Mode.



4. Tap **Done**.

5. Connect your computer to the Mobile Wi-Fi via a USB cable and access the SD card directly.



## Chapter 7

---

# Customize Your Network

---

This chapter guides you on how to configure network settings of your Mobile Wi-Fi.

It contains the following sections:

- [Specify Network Mode](#)
- [Specify Network Band](#)
- [Configure Dial-up](#)
- [Configure DHCP Server](#)




## 7.1. Specify Network Mode


This Mobile Wi-Fi supports three modes of network connection: 4G Preferred, 4G Only and 3G Only. If your SIM card supports WCDMA, select 3G Only; if your SIM card supports FDD-LTE or TDD-LTE, select 4G Preferred or 4G Only as needed. In general, the 4G network is faster than the 3G one.

### Method One: Via the screen

1. Press  (menu button) and switch to the **Network Mode** menu.




2. Press  (power button) to enter the **Network Mode** page.
3. Press  and  to select **4G Pref**, **4G Only** or **3G Only** as needed.



### Method Two: Via the web management page

1. Visit <http://tplinkmifi.net>, and log in with the password you set for the Mobile Wi-Fi.
2. Go to **Device > Advanced > Network Mode**.
3. Select **4G Preferred**, **4G Only** or **3G Only** as needed.



4. Tap **Done**.

## 7.2. Specify Network Band




This Mobile Wi-Fi supports 2.4GHz and 5GHz wireless bands. In general, the 5GHz band performs better, but covers a smaller area .

■ Note: If you have specified 5GHz for Wireless Band, devices that only support 2.4GHz can't connect to the Mobile Wi-Fi.

### Method One: Via the screen

1. Press **≡** (menu button) and switch to the **Wi-Fi Band** menu.




2. Press  (power button) to enter the **Wi-Fi Band** page.
3. Press  and  to specify **2.4GHz** or **5GHz** as needed



### Method Two: Via the web management page

1. Visit <http://tplinkmifi.net>, and log in with the password you set for the Mobile Wi-Fi.
2. Go to **Wireless**.
3. Specify **2.4GHz** or **5GHz** for Wireless Band of your Mobile Wi-Fi.






4. Tap **Done**.

## 7.3. Configure Dial-up

### 7.3.1. Configure Dial-up Settings

If you are in a location beyond your mobile carrier's service area, you may need to configure the dial-up settings to access the internet provided by a local mobile carrier.

1. Visit <http://tplinkmifi.net>, and log in with the password you set for the Mobile Wi-Fi.
2. Go to **Dial-up**.
3. Tap **Create** to build a dial-up profile.
4. Specify a name for the profile and fill in the parameters provided by your carrier.



The screenshot shows a mobile application interface for creating a network profile. The title bar is teal and contains a back arrow, the text "Create Profile", and a "Done" button. The form consists of several sections, each with a label and an input field:

- Profile Name:** A text input field.
- PDP Type:** A dropdown menu currently showing "IPv4".
- APN Type:** A dropdown menu currently showing "Static".
- APN:** A text input field.
- Auth Type:** A dropdown menu currently showing "CHAP".
- Username:** A text input field.
- Password:** A text input field.

5. Tap **Done** and then tap **Yes** in the pop-up to apply the new profile.

■ **Note:**

1. Mobile Data is enabled by default. If disabled, internet access is prohibited.
2. Data Roaming is disabled by default. If enabled, data service is allowed when roaming.
3. You can click [View Profile details](#) to check the current profile. If any parameter is wrong, you can click [Create](#) to build a new one.


### 7.3.2. Configure Network Search

The Mobile Wi-Fi provides two types of network connection: Auto and Manual.

- **Auto:** The Mobile Wi-Fi will automatically establish internet connection when it is started.
- **Manual:** When you have selected **Manual**, click **Search** and the Mobile Wi-Fi will scan for mobile networks. You can choose to connect to a network with better performance. The mobile carrier providing the network must be or have cooperation with your SIM card provider.

1. Visit <http://tplinkmifi.net> from the PC login entry, and log in with the password you set for the Mobile Wi-Fi.

2. Go to [Advanced](#) > [Dial-up](#) > [Network Settings](#).
3. Select [Auto](#) or [Manual](#) for [Network Search](#) as needed.



**Network Search**

Network Search:

- Auto
- Manual

4. Click [Save](#).

## 7.4. Configure DHCP Server

The Mobile Wi-Fi acts as a DHCP (Dynamic Host Configuration Protocol) server, dynamically assigning TCP/IP parameters to devices from the IP Address pool. You can change the settings of the DHCP server if necessary.

1. Visit <http://tplinkmifi.net> from the PC entry, and log in with the password you set for the Mobile Wi-Fi.
2. Go to [Advanced](#) > [DHCP Server](#).
3. Enter a new IP address in the [IP Address](#) field and leave the [Subnet Mask](#) as default. And enter the starting and ending IP addresses in the [Start](#) and [End IP Address](#) fields respectively.

■ Note:

1. The Start and End IP Addresses should be on the same network segment as the IP address you have entered.
2. If you have changed the IP address of your Mobile Wi-Fi, you should use the new IP address or <http://tplinkmifi.net> to log in to the web management page.

### DHCP Server ?

IP Address:	<input type="text" value="192.168.0.1"/>
Subnet Mask:	<input type="text" value="255.255.255.0"/>
Start IP Address:	<input type="text" value="192.168.0.100"/>
End IP Address:	<input type="text" value="192.168.0.199"/>
Lease Time:	<input type="text" value="120"/> minutes (The default value is 120)
Primary DNS Server:	<input type="text" value="192.168.0.1"/>
Secondary DNS Server:	<input type="text" value="0.0.0.0"/> (Optional)

4. Enter the lease time in the [Lease Time](#) field. When the lease time expires, the Mobile Wi-Fi will reassign IP addresses.
5. Enter the primary DNS IP address which usually accords with the IP address.
6. Enter the secondary DNS IP address if provided by your carrier.
7. Click [Save](#).

## Chapter 8

---

# NAT Forwarding

---

The NAT (Network Address Translation) feature makes devices on the LAN use the same public IP address to communicate with devices on the internet, which protects the local network by hiding IP addresses of the devices. However, it also brings about the problem that an external host cannot initiatively communicate with a specified device on the local network.

With the forwarding feature the Mobile Wi-Fi can penetrate the isolation of NAT and allows devices on the internet to initiatively communicate with devices on the local network, thus realizing some special functions.

The Mobile Wi-Fi supports four forwarding rules. If two or more rules are set, the priority of implementation from high to low is Virtual Servers, Port Triggering, UPnP and DMZ.


It contains the following sections:

- [Translate Address and Port by ALG](#)
- [Share Local Resources on the Internet by Virtual Servers](#)
- [Open Ports Dynamically by Port Triggering](#)
- [Make Applications Free from Port Restriction by DMZ](#)
- [Make Xbox Online Games Run Smoothly by UPnP](#)

## 8. 1. Translate Address and Port by ALG

ALG (Application Layer Gateway) allows customized NAT (Network Address Translation) traversal filters to be plugged into the gateway to support address and port translation for certain application layer “control/data” protocols: FTP, TFTP, H323 etc. Enabling ALG is recommended.

1. Visit <http://tplinkmifi.net> from the PC entry, and log in with the password you set for the Mobile Wi-Fi.
2. Go to [Advanced](#) > [NAT Forwarding](#) > [ALG](#).



- **PPTP Passthrough:** If enabled, it allows Point-to-Point sessions to be tunneled through an IP network and passed through the Mobile Wi-Fi.
- **L2TP Passthrough:** If enabled, it allows Layer 2 Point-to-Point sessions to be tunneled through an IP network and passed through the Mobile Wi-Fi.
- **IPSec Passthrough:** If enabled, it allows IPSec (Internet Protocol Security) to be tunneled through an IP network and passed through the Mobile Wi-Fi. IPSec uses cryptographic security services to ensure private and secure communications over IP networks.
- **FTP ALG:** If enabled, it allows FTP (File Transfer Protocol) clients and servers to transfer data via NAT.
- **TFTP ALG:** If enabled, it allows TFTP (Trivial File Transfer Protocol) clients and servers to transfer data via NAT.
- **H323 ALG:** If enabled, it allows Microsoft NetMeeting clients to communicate via NAT.
- **SIP ALG:** If enabled, it allows clients communicate with SIP (Session Initiation Protocol) servers via NAT.

## 8.2. Share Local Resources on the Internet by Virtual Servers

When you build up a server on the local network and want to share it on the internet, Virtual Servers can realize the service and provide it to internet users. At the same time Virtual Servers can keep the local network safe as other services are still invisible from the internet.

Virtual Servers can be used for setting up public services on your local network, such as HTTP, FTP, DNS, POP3/SMTP and Telnet. Different services use different service ports. Port 80 is used in HTTP service, port 21 in FTP service, port 25 in SMTP service and port 110 in POP3 service. Please verify the service port number before the configuration.

**I want to:** Share my personal website I've built in local network with my friends through the internet.

For example, the personal website has been built on my home PC (192.168.0.100). I hope that my friends on the internet can visit my website in some way. The PC is connected to the Mobile Wi-Fi with the WAN IP address 218.18.232.154.

**How can I do that?**

1. Assign a static IP address to your PC, for example 192.168.0.100.
2. Visit <http://tplinkmifi.net> from the PC entry, and log in with the password you set for the Mobile Wi-Fi.
3. Go to [Advanced](#) > [NAT Forwarding](#) > [Virtual Servers](#).
4. Click [Add](#). Click [View Existing Services](#) and select [HTTP](#). The [External Port](#), [Internal Port](#) and [Protocol](#) will be automatically filled in. Enter the PC's IP address 192.168.0.100 in the [Internal IP](#) field.
5. Click [Save](#).

**Virtual Servers** ?

+ Add Delete

<input type="checkbox"/>	ID	Service Type	External Port	Internal IP	Internal Port	Protocol	Status	Modify
--	--	--	--	--	--	--	--	--

Service Name:  View Existing Applications

External Port:  (XX-XX or XX)

Internal IP:

Internal Port:  (XX or Blank, 1-65535)

Protocol:  ▼

Enable this Entry:

Cancel OK

**Tips:**

- It is recommended to keep the default settings of **Internal Port** and **Protocol** if you are not clear about which port and protocol to use.
- If the service you want to use is not in the **Service Type**, you can enter the corresponding parameters manually. You should verify the port number that the service needs.
- You can add multiple virtual server rules if you want to provide several services in the Mobile Wi-Fi. Please note that the **External Port** should not be overlapped.

**Done!**

Users on the internet can enter [http:// WAN IP](http://WAN IP) (in this example: <http://218.18.232.154>) to visit your personal website.

**Tips:**

- The WAN IP should be a public IP address. Users on the internet can also use [http:// domain name](http://domain name) to visit the website.
- If you have changed the default **External Port**, you should use [http:// WAN IP: External Port](http://WAN IP: External Port) or [http:// domain name: External Port](http://domain name: External Port) to visit the website.

## 8.3. Open Ports Dynamically by Port Triggering

Port Triggering can specify a triggering port and its corresponding external ports. When a host on the local network initiates a connection to the triggering port, all the external ports will be opened for subsequent connections. The Mobile Wi-Fi can record the IP address of the host. When the data from the internet return to the external ports, the Mobile Wi-Fi can forward them to the corresponding host. Port Triggering is mainly applied to online games, VoIPs, video players and common applications including MSN Gaming Zone, Dialpad and Quick Time 4 players, etc.

Follow the steps below to configure the Port Triggering rules:

1. Visit <http://tplinkmifi.net> from the PC entry, and log in with the password you set for the Mobile Wi-Fi.
2. Go to **Advanced > NAT Forwarding > Port Triggering**.



3. Click [View Existing Applications](#), and select the desired application. The [Triggering Port](#), [External Port](#) and [Protocol](#) will be automatically filled in. The following picture takes application [MSN Gaming Zone](#) as an example.

4. Click [Save](#).

ID	Application	Triggering Port	Triggering Protocol	External Port	External Protocol	Status	Modify
--	--	--	--	--	--	--	--

Application: MSN Gaming Zone [View Existing Applications](#)

Triggering Port: 47624 (XX)

Triggering Protocol: TCP

External Port: 2300-2400,28800-29000 (XX or XX-XX or XX,XX-XX)

External Protocol: TCP

Enable this Entry:

[Cancel](#) [OK](#)

**Tips:**

- You can add multiple port triggering rules according to your network need.
- The triggering ports can not be overlapped.
- If the application you need is not listed in the Existing Applications list, please enter the parameters manually. You should verify the external ports the application uses first and enter them into [External Port](#) field according to the format the page displays.

## 8.4. Make Applications Free from Port Restriction by DMZ

When a PC is set to be a DMZ (Demilitarized Zone) host on the local network, it is totally exposed to the internet, which can realize the unlimited bidirectional communication between internal hosts and external hosts. The DMZ host becomes a virtual server with all ports opened. When you are not clear about which ports to open in some special applications, such as IP camera and database software, you can set the PC to be a DMZ host.

**Note:**


When DMZ is enabled, the DMZ host is totally exposed to the internet, which may bring some potential safety hazards. If DMZ is not in use, please disable it in time.

**I want to:** Make the home PC join the internet online game without port restriction.

For example, due to some port restriction, when playing the online games, you can login normally but cannot join a team with other players. To solve this problem, set your PC as a DMZ host with all ports open.

### How can I do that?

1. Assign a static IP address to your PC, for example 192.168.0.100.
2. Visit <http://tplinkmifi.net> from the PC entry, and log in with the password you set for the Mobile Wi-Fi.
3. Go to [Advanced](#) > [NAT Forwarding](#) > [DMZ](#) and select [Enable DMZ](#).
4. Enter the IP address 192.168.0.100 in the [DMZ Host IP Address](#) field.



The screenshot shows a configuration window titled "DMZ". At the top right is a help icon (question mark in a circle). The main area contains a "DMZ:" label with a blue toggle switch that is turned on. Below this is a "DMZ Host IP Address:" label followed by a text input field containing "192.168.0.100". At the bottom right of the window is a blue "Save" button.

5. Click [Save](#).

### Done!

The configuration is completed. You've set your PC to a DMZ host and now you can make a team to game with other players.

## 8.5. Make Xbox Online Games Run Smoothly by UPnP

The UPnP (Universal Plug and Play) protocol allows applications or host devices to automatically find the front-end NAT device and send request to it to open the corresponding ports. With UPnP enabled, the applications or host devices on the local network and the internet can freely communicate with each other thus realizing the seamless connection of the network. You may need to enable the UPnP if you want to use applications for multiplayer gaming, peer-to-peer connections, real-time communication (such as VoIP or telephone conference) or remote assistance, etc.

**Tips:**

- UPnP is enabled by default.
- Only the application supporting UPnP protocol can use this feature.
- UPnP feature needs the support of operating system (e.g. Windows Vista/ Windows 7/ Windows 8, etc. Some of operating system need to install the UPnP components).

For example, when you connect your Xbox to the Mobile Wi-Fi which has connected to the internet to play online games, UPnP will send request to the Mobile Wi-Fi to open the corresponding ports allowing the following data penetrating the NAT to transmit. Therefore, you can play Xbox online games without a hitch.

If necessary, you can follow the steps to change the status of UPnP.

1. Visit <http://tplinkmifi.net> from the PC entry, and log in with the password you set for the Mobile Wi-Fi.
2. Go to **Advanced** > **NAT Forwarding** > **UPnP** and toggle on or off according to your needs.

### UPnP

UPnP:

[Save](#)

---

#### UPnP Service List

Client Number: 0 [Refresh](#)

ID	Service Description	External Port	Proto...	Internal IP Address	Internal Port
--	--	--	--	--	--

## Chapter 9

---

# Manage Your Mobile Wi-Fi

---

This chapter presents how to manage and maintain your Mobile Wi-Fi.

It includes the following sections:

- [Save the Mobile Wi-Fi's Power](#)
- [Change Login Password](#)
- [Set Up System Time](#)
- [Restore Configuration Settings](#)
- [Update the Firmware](#)
- [Update ISP Parameters](#)
- [USSD](#)
- [System Log](#)

## 9.1. Save the Mobile Wi-Fi's Power




The Power Saving feature allows you to slow down the power consumption of your Mobile Wi-Fi, by adjusting the Wi-Fi range or enabling the Wi-Fi Auto-disable Time feature.

### Method One: Via the screen

By enabling Power Saving on the screen, the Wi-Fi range will be medium and Wi-Fi Auto-disable time will be 10 minutes.

1. Press  (menu button) and switch to the **Power Saving** menu.




2. Press  (power button) to enter the **Power Saving** page.
3. Press  and  to select **ON**.



### Method Two: Via the web management page

1. Visit <http://tplinkmifi.net>, and log in with the password you set for the Mobile Wi-Fi.
2. Go to **Device > Power Saving**.
  - **To set Wi-Fi Range**
    1. Enable **Power Saving Mode**.
    2. Select **Long**, **Medium** or **Short** from the **Wi-Fi Range** drop-down list.

**Note:**

The shorter the Wi-Fi Range is, the less power your Mobile Wi-Fi uses.


3. Tap **Done**.

4. Tap **Restart Wi-Fi** on the pop-up to make the configurations take effect, and then reconnect to the Wi-Fi after it restarts.

**➤ To set Wi-Fi Auto-disable Time**

1. Enable **Power Saving Mode**.

2. Specify the **Wi-Fi Auto-disable Time**.



3. Tap **Done**. If there are no devices connected to the Mobile Wi-Fi for the time you specified, the Wi-Fi will be disabled automatically.


**Note:**

To resume the Wi-Fi, press the Power Button or the Menu Button.

## 9.2. Change Login Password

This feature allows you to change your login password of the web management page.

1. Visit <http://tplinkmifi.net>, and log in with the password you set for the Mobile Wi-Fi.
2. Go to [Device](#) > [Account](#).
3. Enter the current password. Then enter the new password twice (case-sensitive) and tap [Done](#).



The screenshot shows the 'Account Management' interface. It features a teal header with the text 'Account Management'. Below the header, there is a white input field labeled 'New Password' with a lock icon on the left. Underneath this field are three buttons labeled 'Low', 'Middle', and 'High', which likely represent password strength indicators. Below these buttons is another white input field labeled 'Confirm Password' with a lock icon on the left. At the bottom of the form is a large teal button labeled 'Done'. In the bottom right corner of the screen, there is a 'Skip' button with a right-pointing arrow icon.

4. Use the new password for future logins.


## 9.3. Set Up System Time

The system time you configure here will be used for time-based functions.

**Note:**

Make sure your Mobile Wi-Fi has access to the internet. Otherwise, it can not synchronize the current time.

1. Visit <http://tplinkmifi.net>, and log in with the password you set for the mobile Wi-Fi
2. Go to [Device](#) > [Advanced](#) > [Time Settings](#).
3. Select your local [Time Zone](#) from the drop-down list.



4. Tap **Done**.

## 9.4. Restore Configuration Settings


The Factory Defaults feature allows you to restore your Mobile Wi-Fi to its factory defaults. After you restore your Mobile Wi-Fi, all previous settings will be cleared and you have to reconfigure them.

### Method One: Via the Mobile Wi-Fi

With the Mobile Wi-Fi powered on, remove the cover. Use a pin to press and hold the **RESET** button until the “Power Off” appears on the screen.

### Method Two: Via the web management page

1. Visit <http://tplinkmifi.net> from the PC entry, and log in with the password you set for the Mobile Wi-Fi.
2. Go to **Advanced > Device > Factory Defaults**.
3. Click **Restore**.



4. Wait a few minutes for the restore to complete and the Mobile Wi-Fi to restart.

**Note:** During the resetting process, do not power off the Mobile Wi-Fi.




## 9.5. Update the Firmware


TP-Link is committed to improving product features, giving you a better network experience. We will inform you through the screen and web management page if there's any newly released update firmware. Also, you can download it from the Support page of our website [www.tp-link.com](http://www.tp-link.com).

■ **Note:**

1. Make sure the latest firmware file is matched with the hardware version (as shown in the download section of the Support page).
2. Make sure that you have a stable connection between the Mobile Wi-Fi and your computer.
3. Do NOT power off the Mobile Wi-Fi during the firmware update and make sure it has sufficient power.

### Method One: Via the screen

1. Press  (the power button) to update your Mobile Wi-Fi when the following screen appears.




2. Wait a few minutes for the update to complete and the Mobile Wi-Fi to restart.

### Method Two: Via the web management page

➤ **To update the firmware locally**


1. Download the latest firmware file for your Mobile Wi-Fi from our website [www.tp-link.com](http://www.tp-link.com).
2. Visit <http://tplinkmifi.net> from the PC entry, and log in with the password you set for the Mobile Wi-Fi.
3. Go to **Advanced > Device > Firmware Update**.
4. Select **Update via the local server**, click **Browse** to locate the downloaded file, and then click **Update**.



5. Wait a few minutes for the update to complete and the mobile Wi-Fi to restart.

➤ **To update the firmware online**

1. Visit <http://tplinkmifi.net> from the PC entry, and log in with the password you set for the Mobile Wi-Fi.
2. Go to **Advanced > Device > Firmware Update**.
3. Select **Update via the cloud server**.
4. Click **Update**.



5. Wait a few minutes for the update to complete and the Mobile Wi-Fi to restart.

**Note:**


To download the latest firmware file, you can also click the New Version number, such [1.0.5](#) in the page above. To view update details, click [Release Note](#).

## 9.6. Update ISP Parameters

You can update the ISP information.

1. Download the latest ISP update file from the Support page at [www.tp-link.com](http://www.tp-link.com).
2. Visit <http://tplinkmifi.net> from the PC entry, and log in with the password you set for the Mobile Wi-Fi.

3. Go to [Advanced](#) > [Dial-up](#) > [ISP Update](#).
4. Click [Browse](#) to locate the downloaded file.
5. Click [Update](#).



**ISP Update** ?

If you fail to dial-up Internet access after updating to the latest version, please contact us.

ISP Version: 16070801

New ISP File:  [Browse](#)

[Update](#)


## 9.7. USSD

Unstructured Supplementary Service Data(USSD) allows you to query various information, such as balance from your mobile carrier by sending short codes.

**Note:**

USSD request can't be sent in the 4G Only mode. You can go to [Advanced](#) > [Network Settings](#) to change the mode.

1. Visit <http://tplinkmifi.net> from the PC entry, and log in with the password you set for the Mobile Wi-Fi.
2. Go to [Advanced](#) > [Dial-up](#) > [USSD](#).
3. Enter USSD request codes, click [Send](#) and wait for your mobile carrier's response.



**USSD**

USSD Request:  [Send](#) [Cancel](#)

USSD Response:

**Tips:**

- Please contact with your mobile carrier to obtain the USSD request code.
- The USSD response can be a menu and you can refer to it to obtain the information you need.


## 9.8. System Log

When the Mobile Wi-Fi does not work normally, you can save the system log and send it to our technical support for troubleshooting.

1. Visit <http://tplinkmifi.net> from the PC entry, and log in with the password you set for the Mobile Wi-Fi.
2. Go to [Advanced](#) > [Device](#) > [System Log](#).

### ➤ To save the system logs locally

Click [Save Logs](#) to save the logs to your local device.



The screenshot shows the 'System Log' interface. At the top, there are filters for 'Log Type' (set to ALL) and 'Log Level' (set to ALL). To the right are 'Refresh' and 'Clear' buttons. Below the filters is a table with the following data:


ID	Time	Type	Level	Content
1	10-25 06:34:53	DHCP	INFO	DHCPACK(bridge0) 192.168.0.179 fe:88:1c:6b:db:43 win7-PC
2	10-25 06:34:53	DHCP	INFO	DHCPINFORM(bridge0) 192.168.0.179 fe:88:1c:6b:db:43
3	10-25 06:32:47	4G	INFO	Registered with a network!
4	10-25 06:32:47	4G	INFO	Not registered, searching!
5	10-25 06:32:45	SYSTEM	NOTICE	User clear all logs.

Below the table, there is a 'Debug Log' toggle switch which is currently turned off. At the bottom right, there is a blue 'Save Logs' button.

### ➤ To debug logs

The Debug Log feature can save logs for specific troubleshooting. This function should be enabled under the requirement of our technical support.

1. Insert an SD card of at least 100MB storage in your Mobile Wi-Fi.
2. Put the file provided by our technical support in the SD card.
3. Go to the [Advanced](#) > [Storage Sharing](#) and set [By Wi-Fi](#) as Access Mode.
4. Enable [Debug Log](#).
5. Click [Save Logs](#).
6. Visit the SD card and send the saved files to our technical support.

**Note:**

Do not remove the SD card or switch the storage sharing mode when using this function.

# FAQ


## Q1. What should I do if I cannot log in to the web management page?

- Verify that your device is connected to the Mobile Wi-Fi's SSID.
- Verify that you have entered <http://tplinkmifi.net> or <http://192.168.0.1> correctly.
- Verify that your device is set to obtain an IP address automatically.

## Q2. What should I do when one of the following messages appears on the screen?

### ➤ PIN Required

- Log in to the web management page <http://tplinkmifi.net>. Enter the PIN provided by your mobile carrier and tap **Done**.



### 📌 Tips:

The PIN code of your SIM card is preset by your mobile carrier and usually can be found on the package of the SIM card.

### ➤ No SIM Card

- Power off the Mobile Wi-Fi and reinsert the SIM card.

### ➤ No Service

- Verify that your SIM card is an LTE , WCDMA or GSM SIM card.
- Verify that your SIM card is in your mobile carrier' s service area and has sufficient credit.
- Verify that your mobile carrier parameters are correct: Log into the web management page, go to **Dial-up** and tap **View profile details** to check if APN, Username and Password are correct. If not, return to the **Dial-up** page and create a new profile with the correct information. Then tap **Done** and confirm on the pop-up.

### ➤ icon

- Log in to the web management page, and go to [Dial-up](#) to enable [Data Roaming](#).

### Q3. What should I do if my internet speed is slow?


Log in to the web management page and try the methods below:

- If you are experiencing intermittent slow internet connection, go to [Wi-Fi Band](#) to switch between 2.4GHz and 5GHz for better connectivity.
- The 4G network may be temporarily unavailable in your current location. Go to [Network Mode](#) and try a different network.

### Q4. How do I reset the Mobile Wi-Fi to its factory default settings?

- With the Mobile Wi-Fi powered on, remove the cover. Use a pin to press and hold the [RESET](#) button (hole) until [Power Off](#) appears on the screen and then release the button.
- On your computer or tablet, log i nto the Mobile Wi-Fi's web management page. Go to [Advanced](#) > [Device](#) > [Factory Defaults](#) and click [Restore](#).

## COPYRIGHT & TRADEMARKS

Specifications are subject to change without notice.  is a registered trademark of TP-Link Technologies Co., Ltd. Other brands and product names are trademarks or registered trademarks of their respective holders.

No part of the specifications may be reproduced in any form or by any means or used to make any derivative such as translation, transformation, or adaptation without permission from TP-Link Technologies Co., Ltd. Copyright © 2017 TP-Link Technologies Co., Ltd. All rights reserved.



## CE Mark Warning



This is a class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

## OPERATING FREQUENCY(the maximum transmitted power)

2412MHz—2472MHz(20dBm)

5180MHz—5240MHz(23dBm)

## EU declaration of conformity

TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of directives 2014/53/EU, 2009/125/EC and 2011/65/EU.

The original EU declaration of conformity may be found at <http://www.tp-link.com/en/ce>.

## RF Exposure Information

This device meets the EU requirements (2014/53/EU Article 3.1a) on the limitation of exposure of the general public to electromagnetic fields by way of health protection.

This device has been tested and meets the ICNIRP exposure guidelines and the European Standard EN 62209-2. SAR is measured with this device at a separation of 0.5 cm to the body, while transmitting at the highest certified output power level in all frequency bands of this device. Carry this device at least 0.5 cm away from your body to ensure exposure levels remain at or below the as-tested levels.



Продукт сертифіковано згідно с правилами системи УкрСЕПРО на відповідність вимогам нормативних документів та вимогам, що передбачені чинними законодавчими актами України.



## Safety Information

- Keep the device away from water, fire, humidity or hot environments.
- Do not attempt to disassemble, repair, or modify the device.
- Do not use damaged charger or USB cable to charge the device.



- Do not use any other chargers than those recommended.
- Do not use the device where wireless devices are not allowed.
- Do not disassemble, crush, puncture, short external contacts, or dispose of the battery in fire or water..
- CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of the device. Please use this product with care and operate at your own risk.

**For EU/EFTA, this product can be used in the following countries:**

AT	BE	BG	CH	CY	CZ	DE	DK
EE	EL	ES	FI	FR	HR	HU	IE
IS	IT	LI	LT	LU	LV	MT	NL
NO	PL	PT	RO	SE	SI	SK	UK

### Explanations of the symbols on the product label

Symbol	Explanation
	DC voltage
	<p>RECYCLING</p> <p>This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment.</p> <p>User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.</p>